Golfboy

Usage Guidelines

Follow these setup instructions carefully.

For technical questions or issues

golfboy@qoncept.co.jp


Tripod (GBpod) Assembly

Be sure to watch the video before assembling.

https://youtu.be/OZ_NPzrAfi8?si=_Eui4MfrCkIvEM5F

Set Height in App

Ensure the tripod height matches the in-app setting to maintain measurement accuracy.



Adjust Distance (Customize Ball)

Correct for errors due to ball type, setup, and conditions
(e.g., wind) via the “Setting icon” on the measurement screen.



Strongly Recommended

Select a custom ball and use one that you’ve fine-tuned to match your preferences.

Adjust Shot Direction

Align the iPhone (camera) to 0 degrees for the shot direction.




Mat Length


For indoor use, ensure the mat extends 5 feet to detect shots.




Ball-to-Tripod Distance

Position the ball approximately 1 foot from the tripod.






Turn the iPhone upside down.




The iPhone is mounted **upside down** in the holder.


Even if you look right after hitting, **the numbers are not upside down**.



NG
No mat in the launch direction
(White concrete is a problem)


OK
Extend the mat


NG
No mat in the launch direction
(White concrete is a problem)


OK
Extend the mat


NG
iPhone tilt is too strong
Distance is too far


OK
Tilt the iPhone moderately
Move closer



Distance between tripod and ball

1.0~1.3 ft
(30~40 cm)



iPhone tilt





A NEW 3D SIMULATOR IS NOW AVAILABLE FOR USE ON “iPad” OR “EXTERNAL DISPLAYS”.



Two Methods for Implementing the 3D Simulator

To use this feature, you need either

Premium Plan or **Basic Plan with RoundCast purchase**

Using wirelessly with iPhone and iPad:

- Select [Shot] on the iPhone
- Select [3D Simulator] on the iPad



Using with iPhone and external display:

- Connect the iPhone to the display
  via HDMI or a wireless method such as AirPlay
- Select [Round] on the iPhone



Gimmicks in the 3D Simulator

Shot distance varies depending on the landing area on the course.

[Simulator Gimmick List]
-Fairway: Same shot distance as usual (no slowdown)

-Rough: Run distance is reduced

-Bunker: Launch angle is limited (30° → 25° → 20° → 15°)
; failed shots result in lower angles

-Trees: Can be cleared with a height of 5m or more
; lower shots will hit branches. If in the woods,
you must escape with a low shot under 2m

-Water/OB: Replay the shot (+1 stroke)



